

Assembly Instruction

Step 1

Take out the GO-KART from carton.



Step 2

Take off the steel frame.



Step 3

Install both the front shocks and tighten the nuts.



Step 4

Install the Ball Head into the Turning Arm, tighten the Castle Nut and insert the cotter Pin.



Step 5

Install Front Tires and tighten the nuts.



Step 6

Install both the rear shocks and tighten the nuts.



Assembly Instruction

Step 7

Install Rear Tires, tighten the nuts and insert cotter Pin.



Step 8

Install the two seats, fixup them with bolts and nuts from the bottom of the frame.



Step 9

Fix the safety belt on the frame with a bolt and a nut, tighten them with tools.



Step 10

Fix the steering wheel on the rivet board and tighten the six screws.



Step 11

Put the protection pole cover on the frame and install the bolts and washers, tighten the nuts.

