
LIGHTING SWITCH
KILL SWITCH
STARTING SWITCH
FRONT BRAKE SWITCH
IGNITION LOCK SWITCH
R.TURNING INDICATOR LIGHT
REAR BRAKE SWITCH
FLASHER RELAY
FULE SENSOR
C.D.I
GROUND
SIDE-STAND KILL SWITCH
BUG (STANDBY)
L,TURNING INDICATOR LIGHT
FAR LRRIDATION INDICATOR
INSTRUMENT LIGHT
INSTRUMENT LIGHT
INSTRUMENT LIGHT
BRAKE INDICATOR LIGHT
R,TURNING INDICATOR LIGHT
OIL INDICATOR
VOLTAGE METER
REV METER
DECORATE LIGHT
RIGHT TURNING LIGHT.R
REAR LAMP/BRAKE LIGHT
LEFT TURNING LIGHT.L
LICENSE LIGHT
TALECONTROL (STANDBY)
FUSE-WIRE
15A
12V6Ah
BATTERY
DIMMER SWITCH
HORN SWITCH
TURNING LIGHT SWITCH
HORN
FRONT LIGHT
POSITION LIGHT
ACCEL ERATOR
SPARK PLUG
IGNITION COIL
MAGNETO
START ELECTRICAL
START RELAY
RIGHT TURNING LIGHT.F